

Part No. 12790 (12794, 95)
Front Fender Scoops (Pr.)
2005-09 Mustang (All
Models)



PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE PROCEEDING

We have provided complete instructions and hardware; the list of these items is listed on page 3 of the instructions.

- Before starting **please verify** that the instructions and hardware are included with the shipment. Also, **verify** that you received the correct part(s). All part numbers are embossed on the inside of the urethane component(s).

Tools and general materials required: Acetone or MEK, Burgundy Scotchbrite pad, cleaning cloths

THERE ARE FOUR PHASES TO MOST INSTALLATIONS:

1. Removal of factory parts and then **TEST FIT** the aftermarket product
2. Preparation of the parts for paint and painting
3. Installation of the adhesive tape
4. Installation of the part

PHASE 1) REMOVAL & TEST FIT

- **REMOVAL:** Remove the GT or any other emblem from the front fender.
- **TEST FIT** the parts to verify excellent fit

DO NOT PREP, DRILL, OR PAINT THE PARTS UNTIL TEST FITTING IS COMPLETE.

NOTE:

Urethane parts might seem to be slightly distorted upon test fit. If so, place them in the sun topside down (if a warm day) or in a warm area, approximately 70-80 degrees F, for 2-3 hours and it will return to its original shape and become more flexible.

PHASE 2) PREPARATION OF URETHANE PART (S) FOR PAINTING:

This process is following an approved Sherwin Williams procedure and materials. Consult your paint supplier for equivalent materials and / or procedures.

- WASH the paintable surfaces with a heavy duty detergent degreaser i.e....Castrol purple stuff, Palmolive liquid dish soap, red hot, and USP90 scuff gel, using a gray scuff pad until the part is dull and then rinse thoroughly.
- SAND across item with 400 grit or finer paper and check for imperfections. Repair as needed.
- RE-WASH with heavy detergent degreaser and USP90 scuff gel or Palmolive liquid dish soap using gray scuff pad to remove any residue. Rinse thoroughly and wipe dry with a lint free towel.
- WIPE item down using SC159 plastic and anti-static cleaner with lint free towel.
- SPRAY item with UPO7227 plastic adhesion promoter.
- SPRAY item with P30 sealer base coat then clear coat.
- **DO NOT oven bake our parts above 100 degrees F.** They should be well supported during any heat cycle to avoid the flexible part from warping.



Figure #1 (Driver's Side Shown, Inside)

PHASE 3) INSTALLATION OF THE ADHESIVE TAPE (perform in a warm area above 70 Degrees)

- REMOVE 1/2" masking tape from the backside of the part.
- REMOVE any paint over spray on the tape area of the part with acetone and if needed use 3M #7447 Scotchbrite burgundy pad. After paint over spray is removed wipe tape ledge with a clean rag and acetone.

- **CLEAN** the tape ledge on the inside of the part with MEK or Acetone.
- **ROUGH** up the tape ledge using 3M burgundy Scotchbrite pad that has been dipped in MEK or Acetone and then wipe clean with the MEK or Acetone.
- **APPLY** the provided 3M adhesion promoter, #4298, onto the part and **PRESS** the tape on with the handle part of scissors. There should be 2 rows (next to each other) on the trailing inside edge of the part (the edge next to the door edge) and a single row of tape around the balance of the part- **SEE FIGURE #1**.
- **ALLOW** the part to set with the tape applied for about 30 minutes – this will help the curing process, before installing the product on vehicle.

PHASE 4: INSTALLATION OF THE PART (Perform in a warm area of 70 degrees)

- **INSTALL** the black vinyl inserts into the scoop area being careful to align them correctly. Remove the protective backer on the back side of the insert and press into place.
- The part needs to be warm which will increase it's flexibility and the ease of installation
- **CLEAN** the area which the tape will contact the vehicle with acetone or MEK.
- **REMOVE** the red tape backing from the **INSIDE** row of tape on the back edge of the part.
- **PULL** all the ends of the outside rows of the tape red back liner outside the edge of the part so you can pull them when the part is in place.
- **SET** the part in place, lining up with the top and bottom character body lines and the line at the front fender flare and slowly pull the red liner from the outer rows of tape and press the part snugly into position.
- Allow the parts that were installed to cure at least 12 hours and do not wash the vehicle for at least 48 hours.

PART NUMBER (S):

**Kit #12790 (Consists of 12794 & 12795 parts)
Front Fender Scoops (2005-09 Ford Mustang)**

HARDWARE PROVIDED:

**(3) - 3M4298 adhesive packs, (12)-Feet, 1/2" x .060 tape, left and right scoop black vinyl inserts
(1) set, instructions**

**DATE:
AMERICAN BEST CAR PARTS**

**Revised: May 20, 2009
File: Shared- Doc Folder:**

XENON

12790 Fender Scoop Instructions

**2891 VIA MARTENS
ANAHEIM CA 92806
714-632-1709 Phone www.teamxenon.com**