



2891 Via Martens Anaheim, CA. 92806
Phone: 714.632.1709 Fax: 714.632.2738

PART # 8760 Fender Flare Kit (4 pieces) 2004 Ford F-150 (All Models)



PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE PRECEDING

We have provided complete instructions and in most applications specific hardware, 3M tape, and specialized brackets or braces. The list of these items is listed on page two of the instructions --Before starting please verify that they are included with the shipment.

Also, verify that you received the correct part. All part numbers are embossed on the inside of the urethane component(s). The list of part(s) and hardware provided is noted at the bottom of page 2.

Tools & general materials required: #7447 Scotchbrite pads, TSP or TING cleaners, sandpaper, various hand tools as required, drill, and a 5/64" drill bit

THERE ARE FOUR PHASES TO MOST INSTALLATIONS:

- 1) Removal of factory parts that might interfere with the installation and then TEST FIT the parts
- 2) Preparation of the parts for paint--and painting
- 3) Installation of the 3M tape (If Applicable)
- 4) Installation of the parts

PHASE 1: REMOVAL & TEST FIT

-REMOVE: all fender trim, mud flaps, etc.

-TEST FIT: the parts to verify excellent fit--outline their location with a grease pencil if required

-NOTE: If the fender flares are NOT going to be painted, wash them well with "Simple Green" and when dry, protect them with either 303 Protectant or The Wax Shop "Bumper Black."

DO NOT PREP, DRILL OR PAINT THE PARTS UNTIL THIS IS DONE.

NOTE: Occasionally, our urethane parts might seem to be slightly distorted upon test fit. If so, place them in the sun Face Up (if a warm day) or in a warm area for an hour or more and they should return to their original shape.