



*Body Styling Kits! • Sport Flares*

2891 Via Martens Anaheim, CA. 92806

Phone:714.632.1709 Fax: 714.632.2738

**PART # 8791, 8793, 8792, 8794, 8795, 8797, 8796, 8798**

**Fender Flares 2003-04 Hummer H2**



**PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE PRECEDING**

We have provided complete instructions and in most applications. Specific hardware, 3M tape, and specialized brackets or braces are included. The list of these items is listed on page three of the instructions. Before starting please verify that they are included with the shipment. Also, verify that you received the correct part. All part numbers are embossed on the inside of the urethane component(s). The list of part(s) and hardware provided is noted at the bottom of page 3.

**Tools & general materials required:** #7447 Scotch brite pads, TSP or TING cleaners, sandpaper, various hand tools as required, drill, and a 1/4 and 7/64" drill bit

**THERE ARE FOUR PHASES TO MOST INSTALLATIONS:**

- 1) Removal of factory parts that might interfere with the installation and then TEST FIT the parts
- 2) Preparation of the parts for paint--and painting
- 3) Installation of the 3M tape (If Applicable)
- 4) Installation of the parts

**PHASE 1: REMOVAL & TEST FIT**

**REMOVE:** You will not need to remove any factory parts for this install. (Our bumper cover is designed to surround the factory lights.)

**TEST FIT** the parts to verify excellent fit--outline their location with a grease pencil if required

**DO NOT PREP, DRILL OR PAINT THE PARTS UNTIL THIS IS DONE.**

**NOTE:** Occasionally, our urethane parts might seem to be slightly distorted upon test fit. If so, place them in the sun bottom side down (if a warm day) or in a warm area for an hour or more and they should return to their original shape.