



Part No 90700

Jeep TJ 6" front fender Flare support Kit (pair)

For: 97-06 Jeep TJ Front Flat Panel Flares #9071 & #9072

PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE PROCEEDING

We have provided complete instructions and specific hardware, The list of these items is listed on the page 2 of the instructions.

--Before starting please verify that they are included with the shipment. Also, verify that you received the correct part(s).

Tools and general materials required: Sockets, socket wrench and hand wrenches

THERE ARE TWO PHASES TO THIS INSTALLATION:

- 1) Removal of some mounting hardware
- 2) Installation of the #90700 support panels (left and right)

PHASE 1) REMOVAL OF FRONT RIGHT AND LEFT FLARES

- REMOVE the oval side marker light from the flare and save (do not disconnect the wires)
- REMOVE the mounting hardware from holes #3, #4, #5 and #6 (the first front mounting hole is considered #1)

IMPORTANT: At this point it is important that the Jeep be in the sun on a warm day or in a well heated area. This heat will allow the flare to seek it's as molded shape after the support panel is installed.

PHASE 2) INSTALLATION OF THE SUPPORT AND FENDER FLARE

-WITHOUT letting the flare cool place the support panel under the flare remembering that the first hole in the support panel aligns with the mounting hole #3 in the body, Secure the support

Page Two

panel with the provided four 1/4 x 20 x 1" bolts, washers and nylock nuts and tighten these 4 fastners after aligning the top of the flare so it is flat.

-REINSTALL the side marker light assembly.

PART NUMBER(S): 90700 Right and left support panels (90701 and 90702)

HARDWARE PROVIDED: (1 EA)-Left and Right Support Plates, (8)- 1/4' x 20 x 1" stainless steel bolts, (8)- stainless steel washers, (8)-1/4" x 20 nuts, (1) set instructions

DATE: May 27, 2009

**AMERICAN BEST CAR PARTS
XENON
2891 VIA MARTENS
ANAHEIM CA 92806
714-632-1709 PHONE
www.teamxenon.com**

**File: Shared- Doc Folder:
90700 Support Panel Instructions**