



Part No 90800

Jeep YJ 6" front fender Flare support Kit (pair)

For: 87-96 Jeep YJ Front Flat Panel Flares #9081 & #9082

PLEASE READ INSTRUCTIONS THOROUGHLY BEFORE PROCEEDING

We have provided complete instructions and specific hardware, The list of these items is listed on the page 2 of the instructions.

--Before starting please verify that they are included with the shipment. Also, verify that you received the correct part(s).

Tools and general materials required: Sockets, socket wrench and hand wrenches, 1/4" drill bit and drill.

THERE ARE TWO PHASES TO THIS INSTALLATION:

- 1) Removal of the Xenon flares and drilling
- 2) Installation of the #90800 support panels (left and right)

PHASE 1) REMOVAL OF FRONT RIGHT AND LEFT FLARES

-REMOVE the oval side marker light from the flare and save (do not disconnect the wires)
-REMOVE the Xenon flat panel flares and place them in the sun (on a warm day) or in a warm area with the flares setting on a flat surface mounting hole side down

PHASE 2) INSTALLATION OF THE SUPPORT AND FENDER FLARE

-Drill out the steel fender mounting holes #2, #3 and #4 with a 1/4" drill (the first front mounting hole in the body is considered the #1 hole.

-WITHOUT letting the flares cool install them with the hardware you removed except for holes #2, #3, and #4. Loosely tighten.

Page Two

-SET the support panel in place under the flare and loosely tighten the provided ¼ x 20 x 1” bolt, washer and nylon lock nut. Align the flare and now tighten ALL the mounting hardware.

-REINSTALL the side marker light assembly.

PART NUMBER(S): 90800 Right and left support panels (90801 and 90802)

HARDWARE PROVIDED: (1 EA)-Left and Right Support Plates, (6)- ¼' x 20 x 1” stainless steel bolts, (12)- stainless steel washers, (6)-1/4” x 20 nylock nuts, (1) set instructions

DATE: May 27, 2009

**AMERICAN BEST CAR PARTS
XENON
2891 VIA MARTENS
ANAHEIM CA 92806
714-632-1709 PHONE
www.teamxenon.com**

**File: Shared- Doc Folder:
90800 Support Panel Instructions**